




Assessment of drift potential of sprays produced from tilted shielded rotary atomizers compared to hydraulic nozzles




Sofiene Ouled Taleb Salah, Mathieu Massinon, Nicolas De Cock, Bruno Schiffers and Frederic Lebeau

University of Liege, Gembloux Agro-Bio Tech







Controlled Droplet Application (CDA)... !



Rotary atomiser
(GRASP)






Compromise in terms of droplet sizes ...



Rotary atomiser
(Micromax 120)

- VMD=270
- **Span=0.6**



Horizontal release of droplets




Drift



Anti-drift nozzle
(Hardi Injet 015)

- VMD=325
- **Span=1.1**





To investigate whether a tilted shielded rotary atomizer can reduce drift potential to acceptable levels.

Method

Simulating the behaviour of droplets in the atmosphere




Combined ballistic and random-walk models



Evaporation



Wind profile




Initial conditions:



- Nozzle height= 0.5 m
- Static nozzle
- Crop height= 0.1 m
- Wind velocity= 2 m/s




Assessment of the travelled distance by driftable droplets



Rotary atomiser: VMD=270 μm ; Span=0.6 ; Emitted droplet velocity= 25 m/s




Hydraulic nozzle: VMD=270 μm ; Span=1.1 Emitted droplet velocity= 10 m/s








Droplet behaviour at 2.0 m from nozzle axis



Rotary atomiser: VMD=270 μm ; Span=0.69 ; Emitted droplet velocity= 25 m/s




Hydraulic nozzle: VMD=270 μm ; Span=1.1; Emitted droplet velocity= 10 m/s






Rotary atomiser: VMD=270 ; Span=0.69 ; Emitted droplet velocity= 25 m/s



Volume of driftable droplets collected at 2 m (%)




Volume of driftable droplets collected at 2 m (%)



Hydraulic nozzle: VMD=270; Span=1.1; Emitted droplet velocity= 10 m/s



Volume of driftable droplets collected at 2 m (%)






- **Forward tilted rotary atomisers increased drift relative to vertical orientations.**
- **Vertical rotary atomisers with a narrow droplet size distribution centred around a VMD of 300 μ m reduce drift comparatively to hydraulic nozzles.**
- **A monodisperse droplet size distribution may avoid spray drift.**



**THANK YOU FOR YOUR
ATTENTION**



Δ adhesion, ● rebond, × fragmentation